



Motorola Defy Midframe Replacement

Replace the midframe.

Written By: Geoff Wacker



INTRODUCTION

Use this guide to replace the midframe on your Motorola Defy.



TOOLS:

- [T5 Torx Screwdriver](#) (1)
 - [64 Bit Driver Kit](#) (1)
 - [Magnetic Project Mat](#) (1)
 - [Metal Spudger](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — Rear Case



- Using the screwdriver and the T-5 bit, unscrew the seven 5 mm screws around the outside of the phone.

Step 2



- Remove the back cover of the phone by sliding the bottom black button to the unlock position and lifting it up.

Step 3 — Battery



- Use a plastic opening tool to pry the battery out of the phone.

Step 4 — Midframe



- Unscrew the two silver screws located at the top of the back of the phone.

Step 5



- Use a plastic opening tool to gently pry the midframe from the rest of the phone.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-11-07 05:43:23 AM.